

STEP ONE:

Attach C3 connectors to outside holes of Superbase as illustrated.



STEP TWO:

Connect four Superlever panels to C3 connectors



STEP THREE:

Connect two Stagger pieces to C3 connectors.



STEP FOUR:

Attach C3 connectors to tops of Stagger pieces.

STEP FIVE:

Repeat steps two, three and four until desired height is reached. Finish with either C2 connectors or C3 connectors and a top Superlever Panel.

NOTE: In order for Supercolumn to rotate in the same direction, Stagger pieces must be oriented the same way.

