



STEP ONE

Hold Turbine vertically. A metal rod is attached to the front fabric, hanging freely.

STEP TWO

Stretch fabric outward to insert pin into grommet attached to back fabric.

